

InstaSeal® WELDED SPRINKLER FITTINGS MODEL IS-W2 1"

#### The Viking Corporation, 5150 Beltway Dr. SE Caledonia, MI 49316

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com Visit the Viking website for the latest edition of this technical data page www.vikinggroupinc.com

### 1. DESCRIPTION

The Viking InstaSeal® welded sprinkler fittings are designed to allow hand-tightening of threaded sprinklers. The gasket seals the connection upon sprinkler installation and eliminates the need for additional sealants (PTFE tape or thread sealant) typically used for sprinkler installation.

#### LISTINGS AND APPROVALS 2.



cULus Listed: EX28508

FM Approved: Class 1920

3. TECHNICAL DATA Available since 2023

Materials of Construction:

Fitting: ASTM A106 Gasket: EPDM Rubber Alignment tool: Nylon reinforced plastic Cap: LDPE Pressure rating: 175 psi (12 bar)





WARNING: Cancer and Reproductive Harmwww.P65Warnings.ca.gov

### **Ordering Information**

Viking InstaSeal® fittings are pre-fabricated and welded onto the pipe. Please contact Viking SupplyNet for more information. These are custom order products and can not be returned or refunded.

Ordering Information		
Available sizes (Outlet size x pipe size)	1" NPT x 2" — 2.5"	
	1" NPT x 2.5" — 3"	
Pipe	Schedule 10, 30, 40, Bull Moose Eddy Flow, Wheatland MegaFlow, and Wheatland MegaFlow GF	
	Accessories	
Gasket and tool kit	26595 Refer to Figure 2 Kit Contents: • 1 Gasket removal tool • 1 Push-rod (used for installing gaskets) • 1 Nozzle (used for installing gaskets) • 6 Gaskets, 1"	
1" Replacement gaskets	25712M/W *** This part number is for quantity 1 gasket. Specify the desired quantity when ordering. ***	
Alignment tool	24838 For use with 3/4" and 1" sprinklers, refer to Figure 2. Fits ONLY ESFR sprinklers. *** Not included with kit 26595.***	




InstaSeal® WELDED SPRINKLER FITTINGS MODEL IS-W2 1"

The Viking Corporation, 5150 Beltway Dr. SE Caledonia, MI 49316 Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com Visit the Viking website for the latest edition of this technical data page www.vikinggroupinc.com



MARKINGS		
Model	VK IS-W2	
Date of manufacture	[mm/yyyy]	
Outlet size X pipe size range	1" X 2"- 2.5"	
	1" X 2.5"- 3"	
Maximum pressure rating	175 PSI (12 BAR)	



NOTICE: Install ONLY 1" NPT threaded sprinklers directly into the fitting.

The 1" NPT pipe adapter bushing must be installed before installing any threaded 1" NPT pipe or other devices. Refer to Figure 3.


**Figure 1: Markings and Dimensions** 



InstaSeal® WELDED SPRINKLER FITTINGS MODEL IS-W2 1"

The Viking Corporation, 5150 Beltway Dr. SE Caledonia, MI 49316

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com Visit the Viking website for the latest edition of this technical data page www.vikinggroupinc.com





InstaSeal® WELDED SPRINKLER FITTINGS MODEL IS-W2 1"

The Viking Corporation, 5150 Beltway Dr. SE Caledonia, MI 49316 Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com

Visit the Viking website for the latest edition of this technical data page www.vikinggroupinc.com

*NOTICE:* Installing any device that is not a Viking sprinkler into the IS-W2 fitting may cause leaks. Prior to installing devices other than sprinklers, install the pipe adapter bushing as shown below.

Prior to installing any pipe or device that is not a sprinkler:

- 1. Thread the pipe adapter bushing into the fitting.
- 2. Tighten the pipe adapter bushing completely using a pipe wrench.
- 3. Connections made into the adapter bushing after installation into the IS-W2 will still require normal end preparation (for example, PTFE tape).

#### Adapter Bushing 24551



Figure 3: Pipe Adpater Bushing Installation



InstaSeal® WELDED SPRINKLER FITTINGS MODEL IS-W2 1"

The Viking Corporation, 5150 Beltway Dr. SE Caledonia, MI 49316

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com Visit the Viking website for the latest edition of this technical data page www.vikinggroupinc.com

# 4. INSTALLATION

Refer to appropriate NFPA, FM Global, and/or any other applicable installation standards. Also refer to the sprinkler's technical data sheet for information regarding installation of the sprinkler.

# NOTICE

Over-tightening the sprinkler will deform the gasket and cause leaks.

- Do not tighten the sprinkler more than 360 degrees (1 full turn) from initial gasket contact.
- Install the sprinkler by hand or by using the InstaSeal<sup>®</sup> alignment tool.
- DO NOT USE THE SPRINKLER'S STANDARD METAL INSTALLATION WRENCH.
- Do not exceed the maximum torque specified for the sprinkler. Refer to the sprinkler's technical data.

## Seating the Sprinkler

1. Remove the integrity protective cap from the IS-W2 fitting.

## NOTE: DO NOT COMPRESS THE GASKET DURING THE FOLLOWING STEPS.

- 2. Slowly and gently thread the sprinkler into the fitting by hand until you feel resistance (indicates gasket contact).
- 3. Take note of the position of the sprinkler's frame arms before proceeding.

### **Compressing the Gasket**

- 4. Tighten the sprinkler 180 degrees (1/2 turn) for gasket seal. Minimum recommended torque: approximately 3 ft-lbs. Note: The alignment tool may be used to acheive gasket sealing..
- 5. If desired, the sprinkler may be tightened up to an additional 180 degrees (1/2 turn) in order to align the sprinkler frame arms paralell with the pipe. **Maximum recommended torque: approximatley 8 ft-lbs.**
- 6. Remove the sprinkler's protective cap before placing the system in service.

# NOTICE: DO NOT USE THE SPRINKLER'S STANDARD METAL INSTALLATION WRENCH! INSTALL THE SPRINKLER BY HAND OR USE THE InstaSeal® ALIGNMENT TOOL <u>ONLY!</u>



Figure 4: Sprinkler Installation



InstaSeal<sup>®</sup> WELDED SPRINKLER FITTINGS MODEL IS-W2 1"

#### The Viking Corporation, 5150 Beltway Dr. SE Caledonia, MI 49316

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com Visit the Viking website for the latest edition of this technical data page www.vikinggroupinc.com

#### 5. GUARANTEE

For details of warranty, refer to Viking's current list price schedule or contact Viking directly.

### 6. INSPECTIONS, TESTING, AND MAINTENANCE

### NOTICE

The owner is responsible for maintaining the fire protection system and devices in proper operating condition. For minimum maintenance and inspection requirements, refer to NFPA 25 for Inspection, Testing and Maintenance requirements. In addition, the Authority Having Jurisdiction may have additional maintenance requirements that must be followed.

#### Inspections

The InstaSeal® fittings shoud be inspected and the gasket replaced any time a sprinkler is removed.

#### Testing

Refer to NFPA 25 for Inspection, Testing and Maintenance requirements.

#### Maintenace

The gasket must be replaced whenever a sprinkler is removed.

#### Replacing the Gasket (see Figures 2 and 5)

- 1. Verify that the system has been removed from service. Refer to the system's documentation.
- 2. Remove the sprinkler.
- 3. Remove the old gasket using the pick tool.
- 4. Discard the old gasket.
- 5. Place new gasket (a) into the nozzle (b) with the white colored surface facing out and the chamfered edge going in first (the surface is colored to properly orient the gasket within the nozzle) then place the nozzle into the outlet (c) as shown.
- 6. Line up the insertion tool on the gasket surface ensuring the contact is uniform.
- 7. Press straight on the insertion tool (d) until it contacts the mechanical stop fully seating the nozzle onto the welded fitting.
- 8. Remove the tool and install a new sprinkler.




Figure 5: New Gasket Installation