



**CAUTION: CONCEALED COVER ASSEMBLIES ARE FRAGILE!
TO ASSURE SATISFACTORY PERFORMANCE OF THE PRODUCT, HANDLE WITH CARE.**



**Concealed Sprinkler and Adapter
Assembly with Protective Cap (Pendent
Sprinkler Part No. 06662BA-X shown)**

**Concealed Sprinkler and Adapter
Assembly (Protective Cap Removed)**



**Cover Plate Assembly
(Pendent Cover 12381 shown)**



GENERAL HANDLING AND STORAGE INSTRUCTIONS:

- Do not store in temperatures exceeding 100 °F (38 °C). Avoid direct sunlight and confined areas subject to heat.
- Protect sprinklers and cover assemblies during storage, transport, handling, and after installation.
 - Use original shipping containers.
 - Do not place sprinklers or cover assemblies loose in boxes, bins, or buckets.
- Keep the sprinkler bodies covered with the protective sprinkler cap any time the sprinklers are shipped or handled, during testing of the system, and while finish work is being completed.
- Use only the designated Viking sprinkler wrench (refer to the appropriate sprinkler data page) to install these sprinklers. **NOTE:** The protective cap is temporarily removed during installation and then placed back on the sprinkler for protection until finish work is completed.
- Do not over-tighten the sprinklers into fittings during installation.
- Do not use the sprinkler deflector to start or thread the sprinklers into fittings during installation.
- Do not attempt to remove drywall, paint, etc., from the sprinklers.
- Remove the plastic protective cap from the sprinkler before attaching the cover plate assembly. **PROTECTIVE CAPS MUST BE REMOVED FROM SPRINKLERS BEFORE PLACING THE SYSTEM IN SERVICE!**

FOR COMPLETE CARE, HANDLING, & INSTALLATION INSTRUCTIONS, REFER TO THE SPRINKLER DATA PAGE AND THE APPROPRIATE SPRINKLER GENERAL CARE, INSTALLATION, AND MAINTENANCE GUIDE.

March 10, 2006

Form No. F_070903