VK4921 Standard Response Concealed Pendent Sprinkler K5.6 (80.6)

1. PRODUCT IDENTIFICATION

This document covers the following product, hereafter referred to as "sprinkler":

VK4921: Standard Response, Standard Coverage, Concealed Pendent, K5.6 (80.6) Sprinkler.

2. INTENDED USE

The sprinkler is intended to be used in automatic fire sprinkler systems as allowed by applicable approval authorities. The sprinkler must be used in accordance with:

- 1. the sprinkler's Listings, Approvals, and associated design requirements.
- 2. the recognized design and installations standards issued, for example NFPA, FM, EN, VdS, or LPCB.
- the latest revisions of all applicable manufacturer's documentation.



Figure - 1: VK4921

Governmental codes, ordinances, and standards may apply and may differ from one another.



Cancer and Reproductive Harm www.P65Warning.ca.gov

3. LISTING AND APPROVALS

Refer to section 5 for details and requirements that must be followed.



cULus Listed



FM Approved

VK4921 Standard Response Concealed Pendent Sprinkler K5.6 (80.6)

4. TECHNICAL SPECIFICATIONS

4.1 Definitions

Standard Concealed Pendent Sprinkler: A sprinkler intended to be oriented with the deflector below the frame so that water flows downward through the orifice, striking the deflector and forming an umbrella-shaped spray pattern downward. These sprinklers are designed for installation on concealed pipe systems where the appearance of a smooth ceiling is desired. Concealed sprinklers MUST be used in conjunction with a cover plate assembly.

Corrosion-Resistant Sprinkler: A special service sprinkler with non-corrosive protective coatings, or that is fabricated from non-corrosive material, for use in atmospheres that would normally corrode sprinklers. Standard pendent sprinklers can be ordered as corrosion-resistant sprinklers and can be used with escutcheons when allowed by the approval body.

4.2 Ratings and Physical Characteristics

| Parameter | Value |
|---|------------------------|
| Minimum operating pressure | 7 PSI (0.5 bar) |
| Maximum pressure rating (cULus) | 250 PSI (17.2 bar) wwp |
| Maximum pressure rating (FM) | 175 PSI (12 bar) wwp |
| Factory-tested pressure | 500 PSI (35 bar) |
| Thread size | 1/2" NPT or 15 mm BSPT |
| Nominal K-factor | 5.6 U.S. (80.6) |
| Minimum temperature rating (glass bulb) | _65 °F (–55 °C) |

4.3 Markings and Dimensions




Figure - 2: Markings




Figure - 3: Dimensions

| Ref | Description | Value |
|-----|---|----------------------|
| Α | Listings and Approvals | See sections 3 and 5 |
| В | Manufacturers Sprinkler Identification Number (SIN) | VK4921 |
| С | Manufacture date (year) | See marking |
| D | Maximum pressure rating (cULus) | 250 PSI wwp |
| Е | Nominal temperature rating | See marking |
| F | Height | 2-1/4" (56 mm) |
| G | Nominal pipe engagement | 7/16" (11 mm) |

VK4921 Standard Response Concealed Pendent Sprinkler K5.6 (80.6)

4.4 Materials of Construction

NOTICE: Do not disassemble the sprinkler.




Figure – 4: Sprinkler Components

| Ref | Description | Material |
|-----|--|---|
| 1 | Compression screw | UNS-C36000 |
| 2 | Deflector pins | Stainless steel UNS-S43000 |
| 3 | Deflector | Phosphor bronze UNS-C51000 |
| 4 | Sprinkler frame | QM brass or DZR brass |
| 5 | Pip cap (*not shown) | Copper UNS-C11000 |
| 6 | Pip cap insert | Stainless steel UNS-S30400 |
| 7 | Pip cap T-hinge ring | Stainless steel UNS-S31600 |
| 8 | Vibration dampener ring (**not shown; under Belleville spring) | Buna-N rubber |
| 9 | Belleville spring | Nickel alloy, coated on both sides with PTFE tape |
| 10 | Bulb | Glass, nominal 0.20" (5 mm) diameter |
| 11 | Cover adapter | Cold-rolled steel JIS G3141 and carbon steel UNS-G10100 |
| 12 | Shipping cap | High-density polyethylene |

VK4921 Standard Response Concealed Pendent Sprinkler K5.6 (80.6)







Figure - 6: Thread-On

| Ref | Cover Plate Description | Material |
|-----|---|--|
| 1 | Cover | Copper UNS-C11000 |
| 2 | Base | Brass UNS-C26800 or stainless steel UNS-S30400 |
| 3 | Spring (*not shown) | Beryllium nickel |
| 4 | Solder (**not shown; connects base and cover) | Eutectic |

VK4921 Standard Response Concealed Pendent Sprinkler K5.6 (80.6)

5. LISTING AND APPROVAL DESIGN REQUIREMENTS

5.1 Listing and Approval Specifications

The following tables show the Listings and Approvals available at the time of printing. Check with the manufacturer for any additional approvals. For sprinkler pricing, refer to Viking's current price list.

All available Viking sprinkler base part numbers are approved and/or listed for specific material, equipment, and service standards. The following Approval tables indicate which temperature ratings, sprinkler finishes, and escutcheons (if applicable) each available sprinkler base part number is approved/listed for. To understand each approval specification, refer to this key:



| | Threa | ad Size | Appro | oval Body |
|------------------------|-------|---------|------------------------------|---|
| Sprinkler Base Part | | | cULus | FM |
| Number | NPT | BSPT | Approval Specification | Approval Specification |
| | | | 250 PSI (17 bar) | 175 PSI (12 bar) |
| 24683A | 1/2" | _ | AU1, AS2, BV1, BT2, CV1, CT2 | AU1, AS2, BV1, BX1, BT2, CV1, CX1, CT2 |
| 24683JN ^{1,2} | 1/2" | _ | AU1, AS2, BV1, BT2, CV1, CT2 | AU1, AS2, BV1, BX1, BT2, CV1, CX1, CT2 |
| 23116A | _ | 15 mm | AU1, AS2, BV1, BT2, CV1, CT2 | AU1, AS2, BV1, BX1, BT2, CV1, CX1, CT2 |
| 23116JN ^{1,2} | _ | 15 mm | AU1, AS2, BV1, BT2, CV1, CT2 | AU1, AS2, BV1, BX1, BT2, CV1, CX1, CT2 |

Approval Specification (Sprinkler Temperature Ratings) Key:

 $A = 155 \,^{\circ}F (68 \,^{\circ}C)$

B = 175 °F (79 °C)

C = 200 °F (93 °C)

Approval Specification (Cover Plate Assembly Temperature Ratings) Key:

S = 139 °F (59 °C) stainless steel covers (23193, 23445, 23183, or 23473)³

T = 165 °F (74 °C) stainless steel covers (23193, 23455, 23183, or 23473)

U = 139 °F (59 °C) covers (23190, 23447, 23174, 23463, 23179, or 23482)³

V = 165 °F (74 °C) covers (23190, 23447, 23174, or 23463)

 $X = 165 \,^{\circ}F \, (74 \,^{\circ}C) \, \text{square covers} \, (23197 \, \text{or} \, 23482)$

Approval Specification (Cover Plate Assembly Finishes) Key:

- **1** = Polished chrome, brushed chrome, bright brass, antique brass, brushed brass, brushed copper, painted white, painted ivory, or painted black⁴
- 2 = Stainless steel (painted or not painted)

Footnotes:

- 1. cULus Listed as corrosion-resistant.
- 2. FM Approved as a decorative finish.
- 3. The 139°F (59 °C) covers have an orange label. The 165 °F (74 °C) covers have a white label.
- 4. For white polyester and black polyester, other colors are available upon request with the same approvals as the standard colors.

VK4921 Standard Response Concealed Pendent Sprinkler K5.6 (80.6)

| Comindador | Threa | d Size | Approval Body | | | | |
|----------------------------------|-------|--------|-----------------------------------|----------|----------|-----------------------|--|
| Sprinkler Base Part Number | NPT | BSPT | Additional Listings and Approvals | | | ls | |
| | | | 175 PSI (12 bar) 250 PSI (1 bar) | | | 250 PSI (17 bar) | |
| | | CE | LPCB | UKCA | CCCF | | |
| 24683 | 1/2" | _ | AU1, CV1 | AU1, CV1 | AU1, CV1 | _ | |
| 23116 | _ | 15 mm | AU1, CV1 | AU1, CV1 | AU1, CV1 | _ | |
| 26549 | _ | 15 mm | _ | _ | _ | AU1, AS1, CV1, CT2 | |

Approval Specification (Sprinkler Temperature Ratings) Key:

 $A = 155 \, ^{\circ}F (68 \, ^{\circ}C)$

 $B = 175 \, ^{\circ}F (79 \, ^{\circ}C)$

C = 200 °F (93 °C)

Approval Specification (Cover Plate Assembly Temperature Ratings) Key:

S = 139 °F (59 °C) stainless steel covers (23193, 23445, 23183, or 23473)³

T = 165 °F (74 °C) stainless steel covers (23193, 23455, 23183, or 23473)

U = 139 °F (59 °C) covers (23190, 23447, 23174, 23463, 23179, or 23482)³

V = 165 °F (74 °C) covers (23190, 23447, 23174, or 23463)

 $X = 165 \,^{\circ}F \,(74 \,^{\circ}C)$ square covers (23197 or 23482)

Approval Specification (Cover Plate Assembly Finishes) Key:

- **1** = Polished chrome, brushed chrome, bright brass, antique brass, brushed brass, brushed copper, painted white, painted ivory, or painted black⁴
- 2 = Stainless steel

Footnotes:

- 1. cULus Listed as corrosion-resistant.
- 2. FM Approved as a decorative finish.
- 3. The 139°F (59 °C) covers have an orange label. The 165 °F (74 °C) covers have a white label.
- 4. For white polyester and black polyester, other colors are available upon request with the same approvals as the standard colors.



VK4921 Standard Response Concealed Pendent Sprinkler K5.6 (80.6)

5.2 cULus Listing Requirements and Details

The sprinkler is cULus Listed for installation in the U.S. and in Canada. Installation must be in accordance with the latest edition of NFPA 13 for standard spray sprinklers. This sprinkler is designed for use in light, ordinary, and extra hazard occupancies.

Venting is required for this sprinkler.

5.3 FM Approval Requirements and Details

The sprinkler is FM Approved as standard response Non–Storage upright sprinkler as indicated in the FM Approval Guide. FM Global Loss Prevention Data Sheets contain guidelines relating to, but not limited to: minimum water supply requirements, hydraulic design, ceiling slope and obstructions, minimum and maximum allowable spacing, and deflector distance below the ceiling. For specific application and installation requirements, refer to the latest applicable FM Loss Prevention Data Sheets (including Data Sheet 2–0).

5.4 Additional Approval Requirements and Details

Refer to Table 5.1 for approved configurations allowed by each of the following approvals.

- CE CPR: Standard EN 12259-1:1999 + A3:2006 Declaration of Performance DOP S0021.
- LPCB: Standard EN 12259-1:1999 + A3:2006; Certification Number 096e/06.
- UKCA: Standard EN 12259-1:1999 + A3:2006; Declaration of Conformity UKCA DOC_S5029.
- China Approval: Approved according to China GB standard.

For specific application and installation requirements, refer to the latest applicable governmental codes, ordinances, and standards for the installation location.

5.5 Corrosion-Resistant Coatings

The corrosion-resistant coatings have passed the standard corrosion tests required by the approving agencies and are listed and approved as indicated in Table 5.1. These tests do not represent all possible corrosive environments. The Electroless Nickel PTFE (ENT) finish passed the UL 199 thirty-day corrosion test and is cULus Listed and FM Approved as corrosion-resistant. For automatic sprinklers, the ENT coating is applied to all exposed exterior surfaces, including the waterway.

Prior to installation, verify that the coatings are compatible with, or suitable for, the proposed environment. For questions or concerns about ENT use, contact Viking Corp.

Venting is required for this sprinkler.

5.6 Available Temperature Ratings

Viking sprinklers are available in several temperature ratings that relate to a specific temperature classification. Applicable installation rules mandate the use and limitations of each temperature classification. In selecting the appropriate temperature classification, the maximum expected ceiling temperature must be known. When there is doubt as to the maximum temperature at the sprinkler location, a maximum-reading thermometer should be used to determine the temperature under conditions that would show the highest readings to be expected. In addition, recognized installation rules may require a higher temperature classification, depending upon sprinkler location, occupancy classification, commodity classification, storage height, and other hazards. In all cases, the maximum expected ceiling temperature dictates the lowest allowable temperature classification. Sprinklers located immediately adjacent to a heat source may require a higher temperature rating.



VK4921 Standard Response Concealed Pendent Sprinkler K5.6 (80.6)

6. ORDERING PROCEDURE

6.1 Sprinkler

- 1. Choose a sprinkler base part number with the required thread size and Listing or Approval (refer to section 5):
- 2. Add the suffix for the desired finish.
- 3. Add the suffix for the desired temperature rating.

NOTE: For polyester, insert the desired temperature rating suffix where the dash (–) is shown.

EXAMPLE: 24683AB = VK4921 with brass and 155 °F (68 °C) nominal temperature rating. This sprinkler is to be installed into an area with a maximum ambient temperature of 100 °F (38 °C).

| 1. Sprinkler Base Part Number | | |
|----------------------------------|------------|--|
| See Section 5 | | |
| 24683 | 1/2" NPT | |
| 23116 | 15 mm BSPT | |
| 26549 | 15 mm BSPT | |

| 2. Finish | | |
|-------------|--------|--|
| Description | Suffix | |
| Brass | Α | |
| ENT | JN | |

| 3. Temperature Rating | | | | | |
|----------------------------------|--------|--|--------|--|--|
| Nominal Temperature Rating | | Maximum Ambient Ceiling Temperature | Suffix | | |
| 155 °F (68 °C) | Red | 100 °F (38 °C) | В | | |
| 175 °F (79 °C) | Yellow | 150 °F (65 °C) | D | | |
| 200 °F (93 °C) | Green | 150 °F (65 °C) | Е | | |

VK4921 Standard Response Concealed Pendent Sprinkler K5.6 (80.6)

6.2 Cover Plates

- 1. Select a cover plate base part number:
- 2. Add the suffix for the desired finish.
- 3. Add the suffix for the desired cover plate temperature rating.

EXAMPLE: 23190MC/W = 165 °F (74 °C) temperature rated 2-3/4" (70 mm) diameter round cover plate with a painted white finish.

| 1. Cover Plate Base Part Number ^{1, 5} | | | | | | |
|---|-------------------|--------------------------|--|---------------|--------------------------|--|
| | Thread-On Style | | | Push-On Style | | |
| Base Part Number | Size Inch (mm) | Туре | Base Part Number Size Inch (mm) | | Туре | |
| 23190 | 2-3/4 (70) | Round | 23447 | 2-3/4 (70) | Round | |
| 23174 | 3-5/16 (84) | Round | 23463 | 3-5/16 (84) | Round | |
| 23179 | 3-5/16 (84) | Square | 23482 | 3-5/16 (84) | Square | |
| 23193 | 2-3/4 (70) | Stainless steel round | 23455 | 2-3/4 (70) | Stainless steel round | |
| 23183 | 3-5/16" (70) | Stainless steel round | 23473 | 3-5/16 (84) | Stainless steel round | |

| 2. Finish | | | | |
|-----------------|---------------------|--|--|--|
| Description | Suffix ² | | | |
| Polished chrome | F | | | |
| Brushed chrome | F-/B | | | |
| Bright brass | В | | | |
| Antique brass | B-/A | | | |
| Brushed brass | B-/B | | | |
| Brushed copper | E-/B | | | |
| Painted white | M-/W | | | |
| Painted ivory | M-/I | | | |
| Painted black | M-/B | | | |

| 3. Temperature Ratings ^{3,4} | | | | | | |
|--|-------------------------------|--------------------------|--|--------|--|--|
| Cover Plate Nominal Rating (Required) | Temperature Classification | Sprinkler Nominal Rating | Sprinkler Maximum Ambient Ceiling Temperature | Suffix | | |
| 139 °F (59 °C) | Ordinary | 155 °F (68 °C) | 100 °F (38 °C) | Α | | |
| 165 °F (74 °C) | Intermediate | 175 °F (79 °C) | 150 °F (65 °C) | С | | |
| 165 °F (74 °C) | Intermediate | 200 °F (93 °C) | 150 °F (65 °C) | С | | |

Footnotes

- 1. For complete part number, refer to Viking's current price list.
- 2. Where a dash (-) is shown in the finish suffix designation, insert the desired Temperature Rating suffix. See example above.
- 3. The sprinkler temperature rating is stamped on the deflector.
- 4. Based on NFPA-13. Other limits may apply, depending on fire loading, sprinkler location, and other requirements of the Authority Having Jurisdiction. Refer to specific installation standards.
- 5. Stainless steel cover plates can be painted with either the standard or custom paint colors.

VK4921 Standard Response Concealed Pendent Sprinkler K5.6 (80.6)

6.3 Sprinkler Accessories

For the most appropriate sprinkler accessories, refer to the Approval Charts in section 5.



Figure - 7: Sprinkler Accessories

| Image Reference | Part Number | Description | |
|-----------------|-------------|---|--|
| 1) | 23143 | Installation wrench | |
| 2) | 14412 | Concealed cover plate installation tool | |
| 3) | 14867 | Large concealed cover plate installation tool | |
| 4) | 01731A | Sprinkler cabinet: holds up to 6 sprinklers | |

7. CONTACT

The sprinkler and accessories are available through Viking distributors only. Contact your local Viking sales office, which can be found on our website:

Americas and Asia: www.vikinggroupinc.com/locations OR Europe, Middle East, Africa (EMEA): www.viking-emea.com/contact

Manufacturer:

The Viking Corporation 5150 Beltway SE Caledonia, MI 49316 Tel.: (800) 968–9501 Fax: 269–818–1680

Technical Services: 1-877-384-5464

techsvcs@vikingcorp.com

Importer EU:

Viking S.A. 21, Z.I, Haneboesch L-4562 Differdange / Niederkorn Tel.: +352 58 37 37 – 1 Fax: +352 58 37 36

vikinglux@viking-emea.com

Asia Pacific (APAC) Main Office:

vikingAPAC@vikingcorp.com

The Viking Corporation (Far East) Pte. Ltd. 69 Tuas View Square Westlink Techpark, Singapore 637621 Tel: (+65) 6 278 4061 Fax: (+65) 6 278 4609



OF SPRINKLERS

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com

SPRINKLERS ARE FRAGILE - HANDLE WITH CARE!

General Handling and Storage:

- · Store sprinklers in a cool, dry place.
- Protect sprinklers during storage, transport, handling, and after installation.
- Use the original shipping containers. DO NOT place sprinklers loose in boxes, bins, or buckets.
- Keep sprinklers separated at all times. DO NOT allow metal parts to contact sprinkler operating elements.

For Pre-Assembled Drops:

- · Protect sprinklers during handling and after installation.
- · For recessed assemblies, use the protective sprinkler cap (Viking Part Number 10364).

Sprinklers with Protective Shields or Caps:

- DO NOT remove shields or caps until after sprinkler installation and there no longer is potential for mechanical damage to the sprinkler operating elements.
- Sprinkler shields or caps MUST be removed BEFORE placing the system in service!
- Remove the sprinkler shield by carefully pulling it apart where it is snapped together.
- · Remove the cap by turning it slightly and pulling it off the sprinkler.

Sprinkler Installation:

- DO NOT use the sprinkler deflector or operating element to start or thread the sprinkler into a fitting.
- Use only the designated sprinkler head wrench! Refer to the current sprinkler technical data page to determine the correct wrench for the model of sprinkler used.
- DO NOT install sprinklers onto piping at the floor level.
- · Install sprinklers after the piping is in place to prevent mechanical damage.
- DO NOT allow impacts such as hammer blows directly to sprinklers or to fittings, pipe, or couplings in close proximity to sprinklers. Sprinklers can be damaged from direct or indirect impacts.
- DO NOT attempt to remove drywall, paint, etc., from sprinklers.
- Take care not to over-tighten the sprinkler and/or damage its operating parts!

 Maximum Torque:

1/2" NPT: 14 ft-lbs. (19.0 N-m) 3/4" NPT: 20 ft-lbs. (27.1 N-m) 1" NPT: 30 ft-lbs. (40.7 N-m)



(Original container used)

INCORRECT (Placed loose in box)



CORRECT (Protected with caps)

INCORRECT (Protective caps not used)



CORRECT (Piping is in place at the ceiling)

INCORRECT (Sprinkler at floor level)



CORRECT (Special installation wrenches)



INCORRECT (Designated wrench not used)



A WARNING

Any sprinkler with a loss of liquid from the glass bulb or damage to the fusible element should be destroyed. Never install sprinklers that have been dropped, damaged, or exposed to temperatures exceeding the maximum ambient temperature allowed. Sprinklers that have been painted in the field must be replaced per NFPA 13. Protect sprinklers from paint and paint overspray in accordance with the installation standards. Do not clean sprinklers with soap and water, ammonia, or any other cleaning fluid. Do not use adhesives or solvents on sprinklers or their operating elements.

Refer to the appropriate technical data page and NFPA standards for complete care, handling, installation, and maintenance instructions. For additional product and system information Viking data pages and installation instructions are available on the Viking Web site at www.vikinggroupinc.com.



CARE AND HANDLING OF SPRINKLERS

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsycs@vikingcorp.com

PROTECTIVE SPRINKLER SHIELDS AND CAPS

General Handling and Storage:

Many Viking sprinklers are available with a plastic protective cap or shield temporarily covering the operating elements. The snapon shields and caps are factory installed and are intended to help protect the operating elements from mechanical damage during shipping, storage, and installation. NOTE: It is still necessary to follow the care and handling instructions on the appropriate sprinkler technical data sheets* when installing sprinklers with bulb shields or caps.

WHEN TO REMOVE THE SHIELDS AND CAPS:

NOTE: SHIELDS AND CAPS MUST BE REMOVED FROM SPRINKLERS BEFORE PLACING THE SYSTEM IN SERVICE!

Remove the shield or cap from the sprinkler only after checking all of the following:

- · The sprinkler has been installed*.
- The wall or ceiling finish work is completed where the sprinkler is installed and there no longer is a potential for mechanical damage to the sprinkler operating elements.

SHIELDS AND CAPS MUST BE REMOVED FROM SPRINKLERS BEFORE PLACING THE SYSTEM IN SERVICE!



Figure 1: Sprinkler shield being removed from a pendent sprinkler.



Figure 2: Sprinkler cap being removed from a pendent sprinkler.



Figure 3: Sprinkler cap being removed from and upright sprinkler.

HOW TO REMOVE SHIELDS AND CAPS:

No tools are necessary to remove the shields or caps from sprinklers. DO NOT use any sharp objects to remove them! Take care not to cause mechanical damage to sprinklers when removing the shields or caps. When removing caps from fusible element sprinklers, use care to prevent dislodging ejector springs or damaging fusible elements. NOTE: Squeezing the sprinkler cap excessively could damage sprinkler fusible elements.

- To remove the shield, simply pull the ends of the shield apart where it is snapped together. Refer to Figure 1.
- To remove the cap, turn it slightly and pull it off the sprinkler. Refer to Figures 2 and 3.

NOTICE Refer to the current sprinkler technical data page to determine the correct sprinkler wrench for the model of sprinkler used.



Never install sprinklers that have been dropped, damaged, or exposed to temperatures in excess of the maximum ambient temperature allowed.

* Refer to the appropriate current technical data pages for complete care, handling, and installation instructions. Data pages are included with each shipment from Viking or Viking distributors. They can also be found on the Web site at www. vikinggroupinc.com.



CARE AND HANDLING OF SPRINKLERS

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058
Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com

▲ CAUTION CONCEALED COVER ASSEMBLIES ARE FRAGILE!

TO ASSURE SATISFACTORY PERFORMANCE OF THE PRODUCT, HANDLE WITH CARE.



Concealed Sprinkler and Adapter Assembly with Protective Cap

Concealed Sprinkler and Adapter Assembly (Protective Cap Removed)



Cover Plate Assembly (Pendent Cover 12381 shown)



GENERAL HANDLING AND STORAGE INSTRUCTIONS:

- Do not store in temperatures exceeding 100 °F (38 °C). Avoid direct sunlight and confined areas subject to heat.
- · Protect sprinklers and cover assemblies during storage, transport, handling, and after installation.
- -- Use original shipping containers.
- -- Do not place sprinklers or cover assemblies loose in boxes, bins, or buckets.
- Keep the sprinkler bodies covered with the protective sprinkler cap any time the sprinklers are shipped or handled, during testing of the system, and while ceiling finish work is being completed.
- Use only the designated Viking recessed sprinkler wrench (refer to the appropriate sprinkler data page) to install these sprinklers. **NOTE:** The protective cap is temporarily removed during installation and then placed back on the sprinkler for protection until finish work is completed.
- Do not over-tighten the sprinklers into fittings during installation.
- Do not use the sprinkler deflector to start or thread the sprinklers into fittings during installation.
- · Do not attempt to remove drywall, paint, etc., from the sprinklers.
- Remove the plastic protective cap from the sprinkler before attaching the cover plate assembly. PROTECTIVE CAPS <u>MUST</u> BE REMOVED FROM SPRINKLERS BEFORE PLACING THE SYSTEM IN SERVICE!

Refer to the appropriate current technical data pages for complete care, handling, and installation instructions. Data pages are included with each shipment from Viking or Viking distributors. They can also be found on the Web site at www. vikinggroupinc.com.



CARE AND HANDLING OF SPRINKLERS

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com

USE THE FOLLOWING PRECAUTIONS WHEN HANDLING WAX-COATED SPRINKLERS

Many of Viking's sprinklers are available with factory-applied wax coating for corrosion resistance. These sprinklers MUST receive appropriate care and handling to avoid damaging the wax coating and to assure satisfactory performance of the product.

General Handling and Storage of Wax-Coated Sprinklers:

- Store the sprinklers in a cool, dry place (in temperatures below the maximum ambient temperature allowed for the sprinkler temperature rating. Refer to Table 1 below.)
- · Store containers of wax-coated sprinklers separate from other sprinklers.
- · Protect the sprinklers during storage, transport, handling, and after installation.
- · Use original shipping containers.
- · Do not place sprinklers in loose boxes, bins, or buckets.

Installation of Wax-Coated Sprinklers:

Use only the special sprinkler head wrench designed for installing wax-coated Viking sprinklers (any other wrench may damage the unit).

- · Take care not to crack the wax coating on the units.
- For touching up the wax coating after installation, wax is available from Viking in bar form. Refer to Table 1 below. The coating MUST be repaired after sprinkler installation to protect the corrosion-resistant properties of the sprinkler.
- Use care when locating sprinklers near fixtures that can generate heat. Do not install sprinklers where they would be exposed to temperatures exceeding the maximum recommended ambient temperature for the temperature rating used.
- Inspect the coated sprinklers frequently soon after installation to verify the integrity of the corrosion resistant coating. Thereafter, inspect representative samples of the coated sprinklers in accordance with NFPA 25. Close up visual inspections are necessary to determine whether the sprinklers are being affected by corrosive conditions.

| TABLE 1 | | | | | | |
|---|--------------------|-------------------|---|-------------|--|--|
| Sprinkler Temperature Rating (Fusing Point) | Wax Part Number | Wax Melting Point | Maximum Ambient Ceiling Temperature ¹ | Wax Color | | |
| 155 °F (68 °C) / 165 °F (74 °C) | 02568A | 148 °F (64 °C) | 100 °F (38 °C) | Light Brown | | |
| 175 °F (79 °C) | 04146A | 161 °F (71 °C) | 150 °F (65 °C) | Brown | | |
| 200 °F (93 °C) | 04146A | 161 °F (71 °C) | 150 °F (65 °C) | Brown | | |
| 220 °F (104 °C) | 02569A | 170 °F (76 °C) | 150 °F (65 °C) | Dark Brown | | |
| 286 °F (141 °C) | 02569A | 170 °F (76 °C) | 150 °F (65 °C) | Dark Brown | | |

¹Based on NFPA-13. Other limits may apply, depending on fire loading, sprinkler location, and other requirements of the Authority Having Jurisdiction. Refer to specific installation standards.

AWARNING

Never install sprinklers that have been dropped, damaged, or exposed to temperatures in excess of the maximum ambient temperature allowed.

Refer to the appropriate current technical data pages for complete care, handling, and installation instructions. Data pages are included with each shipment from Viking or Viking distributors. They can also be found on the Web site at www. vikinggroupinc.com.



TECHNICAL DATA

SPRINKLER OVERVIEW

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com

1. DESCRIPTION

Viking fire sprinklers consist of a threaded frame with a specific waterway or orifice size and a deflector for distributing water in a specified pattern. A closed or sealed sprinkler refers to a complete assembly, including the thermosensitive operating element. An open sprinkler does not use an operating element and is open at all times. The distribution of water is intended to extinguish a fire or to control its spread.

Viking sprinklers are available in several models and styles. Refer to specific sprinkler technical data pages for available styles, finishes, temperature ratings, thread sizes, and nominal K-Factors for the particular model selected.

2. LISTINGS AND APPROVALS

Refer to the Approval Charts on the appropriate sprinkler technical data page(s) and/or approval agency listings.



3. TECHNICAL DATA

Pressure Ratings:

Maximum allowable water working pressure is 175 psig (12 Bar) unless rated and specified for high water working pressure [250 psig (17.2 bar)].

Sprinkler Identification:

Viking sprinklers are identified and marked with the word "Viking", the sprinkler identification number (SIN) consisting of "VK" plus a three digit number*, the model letter, and the year of manufacture.

Available Finishes:

Viking sprinklers are available in several decorative finishes. Some models are available with corrosion-resistant coatings or are fabricated from non-corrosive material. Refer to the sprinkler technical data page for additional information.

Available Temperature Ratings:

Viking sprinklers are available in several temperature ratings that relate to a specific temperature classification. Applicable installation rules mandate the use and limitations of each temperature classification. In selecting the appropriate temperature classification, the maximum expected ceiling temperature must be known. When there is doubt as to the maximum temperature at the sprinkler location, a maximum-reading thermometer should be used to determine the temperature under conditions that would show the highest readings to be expected. In addition, recognized installation rules may require a higher temperature classification, depending upon sprinkler location, occupancy classification, commodity classification, storage height, and other hazards. In all cases, the maximum expected ceiling temperature dictates the lowest allowable temperature classification. Sprinklers located immediately adjacent to a heat source may require a higher temperature rating.

K-Factors:

Viking sprinklers are available in several orifice sizes with related K-Factors. The orifice is a tapered waterway and, therefore, the K-Factor given is nominal. Nominal U.S. K-Factors are provided in accordance with the 1999 edition of NFPA 13, Section 3-2.3. Refer to the specific data page for appropriate K-Factor information.

Available Styles:

on the deflector.

Viking sprinklers are available for installation in several positions as indicated by a stamping on the deflector. The deflector style dictates the appropriate installation position of the sprinkler; it breaks the solid stream of water issuing from the sprinkler orifice to form a specific spray pattern. The following list indicates the various styles and identification of Viking sprinklers.

<u>UPRIGHT SPRINKLER:</u> A sprinkler intended to be installed with the deflector above the frame so water flows upward through the orifice, striking the deflector and forming an umbrella-shaped spray pattern downward. Marked "SSU" (Standard Sprinkler Upright) or "UPRIGHT"

<u>PENDENT SPRINKLER:</u> A sprinkler intended to be oriented with the deflector below the frame so water flows downward through the orifice, striking the deflector and forming an umbrella-shaped spray pattern downward. Marked "SSP" (Standard Sprinkler Pendent) or "PENDENT" on the deflector.

Viking Technical Data may be found on The Viking Corporation's Web site at http://www.vikinggroupinc.com. The Web site may include a more recent edition of this Technical Data Page.

CONVENTIONAL SPRINKLER: An "old style" sprinkler intended to be installed with the deflector in either the upright or pendent position. The deflector provides a spherical type pattern with 40 to 60 percent of the water initially directed downward and a proportion directed upward. Must be installed in accordance with installation rules for conventional or old style sprinklers. DO NOT USE AS A REPLACEMENT FOR STANDARD SPRAY SPRINKLERS. Marked "C U/P" (Conventional Upright/Pendent) on the deflector.



TECHNICAL DATA

SPRINKLER OVERVIEW

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058
Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com

- <u>VERTICAL SIDEWALL (VSW) SPRINKLER:</u> A sprinkler intended for installation near the wall and ceiling. The deflector provides a water spray pattern outward in a quarter-spherical pattern and can be installed in the upright or pendent position with the flow arrow in the direction of discharge. Marked "SIDEWALL" on the deflector with an arrow and the word "FLOW". (Note: Some vertical sidewall sprinklers can only be installed in the upright or pendent position—in this case, the sprinkler will also be marked "UPRIGHT" or "PENDENT".)
- <u>HORIZONTAL SIDEWALL (HSW) SPRINKLER:</u> A sprinkler intended for installation near the wall and ceiling. The special deflector provides a water spray pattern outward in a quarter-spherical pattern. Most of the water is directed away from the nearby wall with a small portion directed at the wall behind the sprinkler. The top of the deflector is oriented parallel with the ceiling or roof. The flow arrows point in the direction of discharge. Marked "SIDEWALL" and "TOP" with an arrow and the word "FLOW".
- EXTENDED COVERAGE (EC) SPRINKLER: A spray sprinkler designed to discharge water over an area having the maximum dimensions indicated in the individual listings. Maximum area of coverage, minimum flow rate, orifice size, and nominal K-Factor are specified in the individual listings. EC sprinklers are intended for Light-Hazard occupancies with smooth, flat, horizontal ceilings unless otherwise specified. In addition to the above markings, the sprinkler is marked "EC".
- QUICK RESPONSE (QR) SPRINKLER: A spray sprinkler with a fast- actuating operating element. The use of quick response sprinklers may be limited due to occupancy and hazard. Refer to the Authority Having Jurisdiction (AHJ) prior to installing.
- QUICK RESPONSE EXTENDED COVERAGE (QREC) SPRINKLER: A spray sprinkler designed to discharge water over an area having the maximum dimensions indicated in the individual listing. This is a sprinkler with an operating element that meets the criteria for quick response. QREC sprinklers are only intended for Light Hazard occupancies. The sprinkler is marked "QREC".
- <u>FLUSH SPRINKLER:</u> A decorative spray sprinkler intended for installation with a concealed piping system. The unit is mounted flush with the ceiling or wall, with the fusible link exposed. Upon actuation, the deflector extends beyond the ceiling or wall to distribute water discharge. The sprinkler is marked "SSP", "PEND", or "SIDEWALL" and "TOP".
- CONCEALED SPRINKLER: A decorative spray sprinkler intended for installation with a concealed piping system. The sprinkler is hidden from view by a cover plate installed flush with the ceiling or wall. During fire conditions, the cover plate detaches, and upon sprinkler actuation, the deflector extends beyond the ceiling or wall to distribute water discharge. The sprinkler is marked "SSP", "PEND", or "SIDEWALL" and "TOP".
- RECESSED SPRINKLER: A spray sprinkler assembly intended for installation with a concealed piping system. The assembly consists of a sprinkler installed in a decorative adjustable recessed escutcheon that minimizes the protrusion of the sprinkler beyond the ceiling or wall without adversely affecting the sprinkler distribution or sensitivity. Refer to the appropriate technical data page for allowable sprinkler models, temperature ratings, and occupancy classifications. DO NOT RECESS ANY SPRINKLER NOT LISTED FOR USE WITH THE ESCUTCHEON.
- <u>CORROSION-RESISTANT SPRINKLER</u>: A special service sprinkler with non-corrosive protective coatings, or that is fabricated from non-corrosive material, for use in atmospheres that would normally corrode sprinklers.
- <u>DRY SPRINKLER:</u> A special-service sprinkler intended for installation on dry pipe systems or wet pipe systems where the sprinkler is subject to freezing temperatures. The unit consists of a sprinkler permanently secured to an extension nipple with a sealed inlet end to prevent water from entering the nipple until the sprinkler operates. The unit MUST be installed in a tee fitting. Dry upright sprinklers are marked with the "B" dimension [distance from the face of the fitting (tee) to the top of the deflector]. Dry pendent and sidewall sprinklers are marked with the "A" dimension [the distance from the face of fitting (tee) to the finished surface of the ceiling or wall].
- LARGE DROP SPRINKLER: A type of special application sprinkler used to provide fire control of specific high-challenge fire hazards. Large drop sprinklers are designed to produce an umbrella-shaped spray pattern downward with a higher percentage of "large" water droplets than standard spray sprinklers. The sprinkler has an extra-large orifice with a nominal K-Factor of 11.2. Marked "HIGH CHALLENGE" and "UPRIGHT".
- EARLY SUPPRESSION FAST-RESPONSE (ESFR) SPRINKLER: A sprinkler intended to provide fire suppression of specific high-challenge fire hazards through the use of a fast response fusible link, 14.0, 16.8, or 25.2 nominal K-Factor, and special deflector. ESFR sprinklers are designed to produce high-momentum water droplets in a hemispherical pattern below the deflector. This permits penetration of the fire plume and direct wetting of the burning fuel surface while cooling the atmosphere early in the development of a high-challenge fire. Marked "ESFR" and "UPRIGHT" or "PEND".
- <u>INTERMEDIATE LEVEL/RACK STORAGE SPRINKLER:</u> A standard spray sprinkler assembly designed to protect its operating element from the spray of sprinklers installed at higher elevations. The assembly consists of a standard or large orifice upright or pendent sprinkler with an integral upright or pendent water shield and guard assembly. Use only those sprinklers that have been tested and listed for use with the assembly. Refer to the technical data page for allowable sprinkler models.
- RESIDENTIAL SPRINKLER: A sprinkler intended for use in the following occupancies: one- and two-family dwellings with the fire protection sprinkler system installed in accordance with NFPA 13D; residential occupancies up to four stories in height with the fire protection system installed in accordance with NFPA 13R; and where allowed by the Authority Having Jurisdiction in residential portions of any occupancy with the fire protection system installed in accordance with NFPA 13.



TECHNICAL DATA

SPRINKLER OVERVIEW

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058
Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com

Residential sprinklers have a unique distribution pattern and utilize a "fast response" heat sensitive operating element. They enhance survivability in the room of fire origin and are designed to provide a life safety environment for a minimum of ten minutes. For this reason, residential sprinklers must not be used to replace standard sprinklers unless tested for and approved by the Authority Having Jurisdiction. In addition to standard markings, the unit is identified as "RESIDENTIAL SPRINKLER" or "RES".

4. INSTALLATION

Refer to appropriate NFPA Installation Standards.

5. OPERATION

Refer to the appropriate sprinkler technical data page(s).

6. INSPECTIONS, TESTS AND MAINTENANCE

Refer to NFPA 25 for Inspection, Testing and Maintenance requirements.

7. AVAILABILITY

Viking sprinklers are available through a network of domestic and international distributors. See The Viking Corporation web site for the closest distributor or contact The Viking Corporation.

8. GUARANTEE

For details of warranty, refer to Viking's current list price schedule or contact Viking directly.

IMPORTANT: Always refer to Bulletin Form No. F_091699 - Care and Handling of Sprinklers and the appropriate sprinkler general care, installation, and maintenance guide. Viking sprinklers are to be installed in accordance with the latest edition of Viking technical data, the appropriate standards of NFPA, FM Global, LPCB, APSAD, VdS or other similar organizations, and also with the provisions of governmental codes, ordinances, and standards, whenever applicable. The sprinkler technical data page may contain installation requirements specific for the sprinkler model selected. The use of certain types of sprinklers may be limited due to occupancy and hazard. Refer to the Authority Having Jurisdiction prior to installation.



REGULATORY AND HEALTH WARNINGS

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com

Visit the Viking website for the latest edition of this technical data page www.vikinggroupinc.com

1. DESCRIPTION

Regulatory and Health Warnings applying to materials used in the manufacture and construction of fire protection products are provided herin as they relate to legally mandated jurisdictional regions.

A WARNING

STATE OF CALIFORNIA, USA

Installing or servicing fire protection products such as sprinklers, valves, piping etc. can expose you to chemicals including, but not limited to, lead, nickel, butadiene, titaninum dioxide, chromium, carbon black, and acrylonitrile which are known to the State of California to cause cancer or birth defects or other reproductive harm.

For more information, go to www.P65Warnings.ca.gov

2. WARRANTY TERMS AND CONDITIONS

For details of warranty, refer to Viking's current list price schedule at www.vikinggroupinc.com or contact Viking directly.