

## **TECHNICAL DATA**

2-1/2" & 3" (DN65 & DN80)


MODEL J FLOW CONTROL VALVE

HORIZONTAL STAINLESS STEEL TRIM CHART

Maximum 250 PSI Water Working Pressure

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com Visit the Viking website for the latest edition of this technical data page: www.vikinggroupinc.com



This Trim Chart is for use with the following Viking Trim Sets	
Valve Size	Stainless Steel Trim Part No.
2-1/2" (DN65) & 3" (DN80)	16844

Notes: For use with Trim Chart on Page 2

## **General Notes:**

- Valve must be trimmed as shown. Any deviation from trim size or arrangement may affect the proper operation of the valve.
- All pipe and fittings shall be galvanized or brass except when other materials are specified in the Technical Data for the Halar<sup>®</sup>
  Coated Flow Control Valve or when other materials are specified in the Viking Foam Systems data pages.
- · Gauges are brass as furnished with trim.
- When the Viking Flow Control Valve is used on pre-mixed foam systems, trim piping must be of copper pipe with brass fittings unless
  otherwise specified in the Technical Data for the Halar<sup>®</sup> Coated Flow Control Valve or the Viking Foam Systems data pages.
- Dimensions in parentheses are millimeter and may be approximations.
- Note 1: 1/2" (15 mm) NPT plugged outlet provided for connecting certain optional components and associated trim.
- **Note 2:** Release System Connection: Viking deluge and flow control valves are compatible with hydraulic, pneumatic, and electric release systems. A pneumatic actuator is required on all Viking deluge valves and flow control valves equipped with pneumatic release systems.
- **Note 3:** Alarm Connections: Connect alarm line piping to 3/4" (20 mm) NPT outlet. When using a water motor alarm, a strainer is required. 1/2" (15 mm) NPT outlet is for electric alarm pressure switch.
- **Note 4:** Optional non-interruptible connection for alarm pressure switch to activate electric alarm panel. Note: After the flow control valve trips, this location cannot be shut off. Alarms may operate until the outlet chamber of the flow control valve is de-pressurized below the set point of the alarm pressure switch.



## TECHNICAL DATA

2-1/2" & 3" (DN65 & DN80)
MODEL J FLOW CONTROL VALVE
HORIZONTAL STAINLESS STEEL TRIM CHART

Maximum 250 PSI Water Working Pressure

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com Visit the Viking website for the latest edition of this technical data page: www.vikinggroupinc.com




Figure 2: 1-1/2" and 2" Flow Control Valve Trim




## TECHNICAL DATA


2-1/2" & 3" (DN65 & DN80)
MODEL J FLOW CONTROL VALVE
HORIZONTAL STAINLESS STEEL TRIM CHART

Maximum 250 PSI Water Working Pressure

The Viking Corporation, 210 N Industrial Park Drive, Hastings MI 49058

Telephone: 269-945-9501 Technical Services: 877-384-5464 Fax: 269-818-1680 Email: techsvcs@vikingcorp.com Visit the Viking website for the latest edition of this technical data page: www.vikinggroupinc.com





**Figure 3: Installation Dimensions**